


ALGE-TIMING

# SQUASH



Manual

## Important Information

### General

Before using your **ALGE-TIMING** device read the complete manual carefully. It is part of the device and contains important information about installation, safety and its intended use. This manual cannot cover all conceivable applications. For further information or in case of problems that are mentioned not at all or not sufficiently detailed, please contact your **ALGE-TIMING** representative. You can find contact details on our homepage [www.alge-timing.com](http://www.alge-timing.com)

### Safety

Apart from the information of this manual all general safety and accident prevention regulations of the legislator must be taken into account.

The device must only be used by trained persons. The setting-up and installation must only be executed according to the manufacturer's data.

### Intended Use

The device must only be used for its intended applications. Technical modifications and any misuse are prohibited because of the risks involved! **ALGE-TIMING** is not liable for damages that are caused by improper use or incorrect operation.

### Power supply

The stated voltage on the type plate must correspond to voltage of the power source. Check all connections and plugs before usage. Damaged connection wires must be replaced immediately by an authorized electrician. The device must only be connected to an electric supply that has been installed by an electrician according to IEC 60364-1. Never touch the mains plug with wet hands! Never touch live parts!

### Cleaning

Please clean the outside of the device only with a smooth cloth. Detergents can cause damage. Never submerge in water, never open or clean with wet cloth. The cleaning must not be carried out by hose or high-pressure (risk of short circuits or other damage).

### Liability Limitations

All technical information, data and information for installation and operation correspond to the latest status at time of printing and are made in all conscience considering our past experience and knowledge. Information, pictures and description do not entitle to base any claims. The manufacturer is not liable for damage due to failure to observe the manual, improper use, incorrect repairs, technical modifications, use of unauthorized spare parts. Translations are made in all conscience. We assume no liability for translation mistakes, even if the translation is carried out by us or on our behalf.

### Disposal

If a label is placed on the device showing a crossed out dustbin on wheels (see drawing), the European directive 2002/96/EG applies for this device.

Please get informed about the applicable regulations for separate collection of electrical and electronical waste in your country and do not dispose of the old devices as household waste. Correct disposal of old equipment protects the environment and humans against negative consequences!



### Copyright by **ALGE-TIMING GmbH**

All rights reserved. Any duplication, either in full or in part, requires the prior written consent of the copyright holder.

# Manual SQUASH Scoreboards



## Table of Content

<b>1</b>	<b>Parts of the System .....</b>	<b>4</b>
<u>1.1</u>	<u>Scoreboard .....</u>	<u>4</u>
<u>1.2</u>	<u>Command console D-CKN .....</u>	<u>5</u>
<u>1.3</u>	<u>PC-Keyboard .....</u>	<u>5</u>
<b>2</b>	<b>Commissioning.....</b>	<b>6</b>
<b>3</b>	<b>Operation.....</b>	<b>6</b>
<u>3.1</u>	<u>New Match (Game) .....</u>	<u>6</u>
<u>3.2</u>	<u>Player names and Game information.....</u>	<u>6</u>
<u>3.3</u>	<u>Points, Set and Service .....</u>	<u>7</u>
3.3.1	Operation .....	7
3.3.2	Corrections .....	7

Copyright by:

ALGE-TIMING GmbH  
Rotkreuzstrasse 39  
A-6890 Lustenau  
Telefon: +43 5577-85966  
Fax: +43 5577-85966-4  
e-Mail: [office@alge-timing.com](mailto:office@alge-timing.com)  
Internet: <http://www.alge-timing.com>

## 1 Parts of the System

### 1.1 Scoreboard

The following different scoreboards are available



## 1.2 Command console D-CKN

The command console D-CKN is connected directly to the display board. It is supplied also from the scoreboard.

With the console you can control the points and the game time.



## 1.3 PC-Keyboard

If you have a scoreboard with names you have to use the PC-Keyboard to enter the player-names and other information.

Additionally, it is also possible to control the scoreboard with this keyboard.



## 2 Commissioning

- Mount the scoreboard to a wall or on a suitable tripod.
- Connect the console with the data cable to the scoreboard.
- Connect the PC keyboard to the console. (Only if your scoreboard can show names)
- Connect the power cable to the scoreboard.

## 3 Operation

As soon as you power on the system it shows the standings of the last game.

### 3.1 *New Match (Game)*

Press the ESC button 3-times to enter the menu

ATTENTION! If game time is running you cannot enter this menu!

```
>Continue Match
  Start new Match
  Language
```

- Choose „Continue Match“ to proceed with the current match.
- Choose „Start new Match“ to begin a new match.
- Choose „Language“ to change the language.

### 3.2 *Player Names and Game Information*

To edit the player names and the game information you need to connect the PC keyboard to the console. Then you can proceed as following.

Press the button „Teams“ on the PC keyboard

```
>Player_1
  Player _2
  Tourname
  Clear All
```

After selection of the different fields you can edit the names of the players and the tourname.

### 3.3 *Points, Set and Service*

#### 3.3.1 Operation

- With the key POSS on the game console you can define which player serves first.
- With the Up-Down arrow keys on the command console you can add or delete points.
- If one player reaches 11 points with at least 2 points advantage the set is finished automatically
- If the standing is 11:10 the set remains active till one player has an advantage of 2 points.
- To end the set with a abnormal standing you have to press the button "PERIODE"

#### 3.3.2 Corrections

##### 3.3.2.1 Standings, Set

- You can adjust the standing with the Up-Down arrow keys easily.
- If you have finished a set by accident you reactivate it by pressing the middle „down arrow“ and the „PERIODE“ button.

##### 3.3.2.2 Game time

If you press the button „TIME“ you enter the menu.

ATTENTION! If game time is running you cannot enter this menu!

```
>Enter current time
Time way          up
Adjust Clock
```

- With selection of „Enter current time“ you can edit the time. Quit with “Enter”
- With the selection “Time way” you can choose if the clock shall count up or down.
- The “Adjust Clock” will change the internal daytime of the console.